


SERVICE AGENT CONTACT DETAILS



WAIKATO

Mobility Equipment & Services Ltd
0800 721 212 / 07 578 1213

Seating to Go Ltd
0800 109 433 / 07 848 1825

Waikato Mobility Equipment
07 282 1603

TARANAKI

Meco Engineering Co Ltd (Equipment Only)
06 751 0339 (021 863 260)

Skeletal Services (Hawera Only)
027 281 0780

Taranaki DHB (Wheelchairs Only)
06 753 8657

WHANGANUI

Skeletal Services
027 281 0780

PALMERSTON NORTH

A1 Wheelchair Services (2007) Ltd
0800 222 284 / 06 356 7344

BAY OF PLENTY/ LAKES

Mobility Equipment & Services Ltd
0800 721 212 / 07 578 1213

Seating to Go
0800 109 433 / 07 571 4379

GISBORNE

Eastland Auto Electrical
06 867 9174

HAWKES BAY REGION

Eastland Auto Electrical
06 867 9174

Mobilities Hawkes Bay
06 878 8655

KAPITI/HOROWHENUA

Southend Cycles Ltd
06 368 5459

WAIRARAPA

Evolved Performance Ltd
06 379 5153 (021 211 0051)
0800 515 351

WELLINGTON

Capital Mobility Ltd
04 238 4731

If your equipment requires repair contact the Enable New Zealand service agent in your area.

If the equipment requires permanent or temporary replacement the Enable New Zealand service agent will contact your Assessor or Therapist to discuss your equipment needs.

Enable
NEW ZEALAND®

Ask Enable New Zealand about the
FREE Library Service
Phone 0800 17 1981 or view our library catalogue on
www.weka.net.nz

Enable
NEW ZEALAND®

Palmerston North *Head Office* 69 Malden St,
PO Box 4547, Palmerston North 4442
New Zealand
Phone 0800 ENABLE (362 253)

Email enable@enable.co.nz • web www.enable.co.nz

20/01/2017

ENAS001

**EQUIPMENT
OPERATING
INSTRUCTIONS**

NI


EQUIPMENT OPERATING INSTRUCTIONS

The Safe and Correct Use of Equipment

Your Assessor or Therapist will discuss the use of your equipment with you. If you have any issues regarding the use of the equipment please contact your Assessor or Therapist.

If your equipment came with manufacturer's instructions, please ensure you read these carefully and that you are aware of all safety precautions and user responsibilities associated with the correct use and operation of the equipment.

Some equipment items feature multi-hole adjustments on the legs which facilitates a minimal setting to compensate for uneven floor covering.



Button must protrude by a minimum of 2mm

Electrical Equipment

- Check weekly for worn or damaged cables/wires.
- Do not allow moisture to come into contact with any electrical components or controllers.

Day to Day Care and Maintenance

Under the terms and conditions of the issue of long-term loan equipment, it is your responsibility to ensure that the equipment is properly cared for and maintained in a clean and safe working condition.

General Care and Cleaning

- Clean your equipment weekly using a damp cloth and mild detergent/disinfectant. Ensure no moisture comes into contact with any electrical parts.
- Keep the equipment dry and ensure it is thoroughly dried after cleaning. Placing equipment out in the sun can assist with drying adjustable parts.
- Inspect your equipment monthly for loose or worn parts, torn/frayed material and any unusual noises from moving parts.
- Clean any build-up of hair etc from around wheels and castors.
- Warm machine wash any seat covers or mattress covers.

Regular Maintenance

Some equipment may require regular maintenance that may include:

- Tightening screws (with the exception of cross-arm bolts on manual wheelchairs).
- Tyres can be filled using bike pumps or by visiting your nearest petrol station.
- Ensuring tyre pressure is kept at the correct level. Do not inflate above the pressure noted on the side of the tyre.
- Replacement of worn tips on walking frames and sticks.

Battery Chargers

For equipment using rechargeable batteries.

Operation:

- Ensure the wheelchair/equipment is turned off.
- Plug the battery charger into the socket on the equipment.
- Connect the charger to the mains outlet.
- Turn the charger on at the wall socket.

Hints and Precautions:

- Always recharge batteries nightly after use and charge for as long as possible.
- Some batteries may take as long as 12 hours to fully recharge.
- Charging should only be done at room temperature and in a well ventilated area.

Warranty

Equipment that has been purchased new from a supplier (i.e. not reissued equipment) will come with warranty provisions. Warranty periods may range from six months to three years.

Should your equipment fail and you consider it to be covered under the terms of the supplier's warranty, please advise the Enable New Zealand service agent of the asset number and date you received the equipment.